198A

IMPORTANT SAFETY RULES

Read, understand, and follow all instructions carefully before installing and using this product.

Auto Cleaner



Don't forget to try these other fine Intex products: pools, pool accessories, inflatable pools and in-home toys, airbeds and boats available at fine retailers or visit our website.

Due to a policy of continuous product improvement, Intex reserves the right to change specifications and appearance, which may result in updates to the instruction manual without notice.

©2019 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China.

Trademarks used in some countries of the world under license from/®™ Marques utilisées dans certains pays sous licence de/Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd. to/ála/an Intex Development Co. Ltd., G.P.O Box 28829, Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 - Distributed in the European Union by/Distribué dans l'Union Européenne par/Distribuido en la unión Europea por/Vertrieb in der Europäischen Union durch/Intex Trading B.V., Venneveld 9, 4705 RR Roosendaal – The Netherlands www.intexcorp.com

198-*A*-R0-2006

198A

TABLE OF CONTENTS

Warnings	3
Parts Reference	4
Set Up Instructions	5-9
Debris Net Cleaning	10
Micro-screen Cleaning	11
Troubleshooting Guide	12
Long Term Storage	13
General Aquatic Safety	13

198A

IMPORTANT SAFETY RULES

Read, Understand and Follow All Instructions Carefully Before Installing and Using this Product.

WARNING

- TO REDUCE THE RISK OF INJURY, DO NOT PERMIT CHILDREN TO USE THIS PRODUCT.
- REMOVE THE PRODUCT FROM THE POOL WHILE THE POOL IS OCCUPIED OR IN USE.
- TURN OFF OR UNPLUG THE FILTER PUMP BEFORE ADJUSTING, CLEANING OR SERVICING.
- REMOVE THE PRODUCT FROM THE POOL BEFORE PLACING A POOL COVER OVER THE POOL.
- STORE THE PRODUCT AND ACCESSORIES IN A DRY AND SAFE PLACE INDOORS.
- FOR POOL AND FILTER PUMP PROBLEMS REFER TO THEIR RESPECTIVE OWNER'S MANUAL FOR ADVICE.


FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN PROPERTY DAMAGE. SERIOUS INJURY OR DEATH.

This Filter-Pump system is intended to be used only for the purposes described in the manual! Failure to follow all product, package and package insert safety and installation instructions could result in electric shock, entanglement, other serious injury or death.

198A

PARTS REFERENCE

Before assembling your product, please take a few minutes to check the contents and become familiar with all the parts.



NOTE: Drawings for illustration purpose only. Actual product may vary. Not to scale.

REF. NO.	DESCRIPTION	QTY.	SPARE PARTS NO.
1	CLEANER TOP	1	12857
2	COLLAR NUT	1	11569
3	GEAR MODULE	1	12858
4	DEBRIS NET	1	11751
5	CLEANER BASE	1	11750
6	MICRO-SCREEN	1	12860
7	HOSE ADAPTOR	1	12859
8	HOSE COLLAR NUT	2	12863
9	HOSE	1	12862
10	BRUSH SUPPORT A (WITH 2 EXTRA)	4	11493
11	BRUSH (WITH 10 EXTRA)	12	11567
12	BRUSH SUPPORT B (WITH 2 EXTRA)	4	11494
13	EXHAUST RING PLATE	1	11752
14	CAP SEAL O-RING	2	12861

198A


SETUP INSTRUCTIONS

IMPORTANT PREPARATION INFORMATION

Please read, understand, and follow all instructions carefully before installing and using this product.

General


- The Auto Cleaner must be connected to a filter pump with a flow rate between 1600 - 3500 gallons/hour (6056 - 13248 liters/hour).
- For Intex[®] above ground pools.
- The cleaning performance depends on the filter pump flow rate, the higher the flow rate the better the performance.
- First assemble your filter pump and then set up the auto cleaner.
- If using a sand filter, ensure the sand media is clean by backwashing it first. Run the filter pump for 10-15 minutes before connecting the auto cleaner to the water return connector.
- The auto cleaner will not work if the filter pump is not operating.




198A

SETUP INSTRUCTIONS (continued)


1. Turn off the filter pump. From inside of the pool, unscrew the nozzle from the water return connector. See Fig. 1.



 Make sure the micro-screen (6) is inside the hose adaptor (7), then screw the hose adaptor to the threaded strainer connector, from inside of the pool. See Fig. 2.



3. Screw the hose (9) with the hose collar nut (8) to the hose adaptor (7). See Fig. 3.




198A

SETUP INSTRUCTIONS (continued)

4. Extend the hose **(9)** to the opposite side of the pool wall so that it over hang the wall and cut the excess hose with a scissor, refer to below table and fig 4.

Note: Unscrew (clockwise direction) the hose collar nut **(8)** from the other end of the hose **(9)** before cutting the excess hose. Screw (counter-clockwise direction) the hose collar nut **(8)** back onto the main hose **(9)** after cutting.


Р	Recommend hose length (m)				
INTEX ABOVE GROUND POOLS (AGP's)					
Circular	15' x 42", 15' x 48"	4.5			
	16' x 48", 16' x 52"	5.0			
	18' x 48", 18' x 52"	5.5			
	20' x 48", 20' x 52"	6.0			
	24' x 52", 26' x 52"	6.5			
Oval	16'6" x 9' x 48"	4.0			
	20' x 10' x 48"	4.5			
Rectangular	18' x 9' x 52"	5.0			
	24' x 12' x 52"	6.0			
	32' x 16' x 52"	6.5			




198A

SETUP INSTRUCTIONS (continued)

Brush assembly. See Fig. 5.
 NOTE: Remove the brushes from underneath the device when vacuuming large debris or leaves on the pool floor.



6. From outside of the pool, connect the end of hose with the hose collar nut (8) to the auto pool cleaner inlet.
Vertically insert the hose collar nut (8) into the inlet opening, while pushing down the hose collar nut, turn the inlet rim clockwise to tighten the hose. To remove the hose, turn the inlet rim counter-clockwise. See Fig. 6.




Enalish


198A

SETUP INSTRUCTIONS (continued)

7. Hold the auto cleaner upside down below the water surface to jet out the water. See Fig. 7. This will evacuate all the air in the hose and auto cleaner, so the cleaner will sink to the bottom of the pool floor.



8. Turn on the filter pump and make sure water is flowing through the micro-screen (6) and the hose adaptor (7). The auto cleaner is now moving and vacuuming the pool floor. See Fig. 8.
Note: The cartridge filter pump and sand filter pump will clean the pool water. It's essential to clean or replace the filter cartridge or backwash sand media frequently to keep the water clean.




IMPORTANT NOTE


If the auto cleaner starts to stir the debris, sediments on the pool floor, you will require to clean or replace the filter cartridge more frequently as the fine sediments are retained by the cartridge.


198A


DEBRIS NET CLEANING

- Make sure the filter pump is turned off, and disconnect the power cord from the electrical outlet.
- Lift the auto cleaner's hose slowly then hold the auto cleaner up with both hands. See Fig. 9.
 CAUTION: Do not pull the hose directly which could damage the auto cleaner hose connection fitting.
- 3. Grasp the cleaner base with two hands, lift the auto cleaner up slowly with an angle (either head or tail up). See Fig.10. After the water has been fully released from the auto cleaner, carry the auto cleaner out of the pool and put it on the ground.
- **4.** Unlock the four buckles located on the four sides. See Fig. 11.
- 5. Remove the debris net (4) from the cleaner base (5). If debris is on the debris net and cleaner base, use garden hose to flush the debris off. See Fig. 12.
- 6. Reassemble auto cleaner reversing steps 1, 2, 3, 4 and 5.










Enalish


198A

MICRO-SCREEN CLEANING

- Make sure the filter pump is turned off, and disconnect the power cord from the electrical outlet.
- 2. To remove the hose, unscrew (counter-clockwise direction) the hose collar nut (8) from the hose adaptor (7). See Fig. 13.



3. Unscrew (counter-clockwise direction) the hose adaptor (7) from the threaded strainer connector. Remove the micro-screen (6) from the hose adaptor. Use a garden hose to clean and flush out any debris from the micro-screen and hose adaptor. See Fig. 14.



4. Reassemble all the components back by reversing previous steps.

Enalish

198A

TROUBLESHOOTING GUIDE				
TROUBLE	SOLUTION			
AUTO CLEANER DOESN'T MOVE	 Ensure the filter pump is operating. Lift the auto cleaner out of the water and check if water is flowing out from either end of the device. Tighten hose and hose collar nut securely, and connect the hose to the water return connector, see "Setup" section. If you are not sure which return connector is, try connecting the auto cleaner to each pool outlet until water is flowing out of either end of the device. Lift the auto cleaner out of the wrinkled area, and make sure the pool floor is as smooth as possible. Contact Intex Service Center. 			
MOVEMENT IS VERY SLOW	 Check and clean the debris net and micro-screen. Clean or replace the filter pump cartridge. If using a sand filter, ensure the sand media is clean by backwashing it. See sand filter owner's manual. If you are still not satisfied with the speed, a higher flow rate filter pump is recommended. 			
LIFTS OFF FROM THE POOL FLOOR	 Release the air from the auto cleaner by following the "Setup" instructions. Pool water too dirty. Ensure the pool water chemistry is balanced. If the pool water is green, brown or black, adjust the chlorine and pH level. See pool owner's manual. Check if the pump flow rate is within the specified range, if the flow rate is more than 3500 gal/h, change pump with lower flow rate. 			
CAN NOT PICK UP THE LEAVES ON POOL FLOOR	 Remove the brushes from the underside and put the Auto Cleaner back into the pool, see "Setup" section. Clean all the debris from the Auto Cleaner after operating for 2-3 hours continuously. 			

IMPORTANT

If you continue to experience difficulty, please contact our Consumer Service Department for assistance. See separate "Authorized Service Centers" sheet.

198A

LONG TERM STORAGE

- Make sure the filter pump is turned off, and disconnect the power cord from the electrical outlet.
- Using the Set Up instructions in reverse, disassemble the auto cleaner.
- 3. Clean and air dry all the accessories and parts thoroughly.
- **4.** Loosely roll up and avoid twisting the hose during storage. Do not put heavy objects on top of the hose.
- Remove the brushes and keep them flat and straight during storage.
- The original packaging can be used for storage. Store in a dry, cool storage location.

GENERAL AQUATIC SAFETY

Water recreation is both fun and therapeutic. However, it involves inherent risks of injury and death. To reduce your risk of injury, read and follow all product, package and package insert warnings and instructions. Remember, however, that product warnings, instructions and safety guidelines cover some common risks of water recreation, but do not cover all risks and or dangers.

For additional safeguards, also familiarize yourself with the following general guidelines as well as guidelines provided by nationally recognized Safety Organizations:

- Demand constant supervision. A competent adult should be appointed as a "lifeguard" or water watcher, especially when children are in and around the pool.
- · Learn to swim.
- · Take the time to learn CPR and first aid.
- Instruct anyone who is supervising pool users about potential pool
 hazards and about the use of protective devices such as locked doors,
 barriers, etc.
- Instruct all pool users, including children what to do in case of an emergency.
- Always use common sense and good judgement when enjoying any water activity.
- Supervise, supervise, supervise.