PARTS DESCRIPTION:

AC LINE CORD

SWITCH

6. NOZZLES 7. VENT HOLES / SLOTS

INFLATION CONNECTOR

**DEFLATION CONNECTOR** 


### INTEX® OWNER'S MANUAL **Quick-Fill™ Electric Air Pump**

Model AP640; 220 - 240 Volt ~ 50 Hz; 100 W READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT

- Adult use only.
- Do not drop unit into water or expose unit to rain or water.
- Do not direct air stream at face or body.
- Do not operate for more than 10 minutes at a time. Unplug and let cool at least 10 minutes.
- Unplug unit when not in use.
- Do not obstruct vent holes or open source.
- Do not insert objects into the inflation or deflation connector.
- The AC supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- To reduce the risk of electric shock, do not expose to rain. Store indoors.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE ELECTRIC SHOCK, BURNS OR OTHER INJURY.

### NAMES OF PARTS



NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale

### INSTRUCTIONS

### General

- · Return pump and nozzles to package when not in use.
- · No specific air pump maintenance is required.

## SAVE THESE INSTRUCTIONS

203-\*\*\*-R0-2005 Page 1

### 203


# CAUTION

In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

### INSTRUCTIONS


### INFLATION

- 1. Attach nozzle to the inflation connector if necessary and hold pump against inflation valve on item to be inflated.
- NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster inflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc.
- 2. Plug in the AC line cord into an AC electrical outlet. See Fig (2).
- 3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3)



### DEFLATION

- 1. Attach nozzle to the deflation connector if necessary and hold pump against inflation valve on item to be deflated.
- NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster deflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc.
- Plug in the AC line cord into an AC electrical outlet. See Fig (2).
- 3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3)



©2019 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprime en Chine/Impreso en China/Gedruckt in China. Order to China/Gedruckt in China. Order to China/Gedruckt son tiene de Marcas registradas utilizadas en algunos paises del mundo bapo licencia de/Marcas registradas utilizadas en algunos paises del mundo bapo licencia de/Marcas registradas configurados en de/Marcas registradas utilizadas en algunos paises del mundo bapo licencia de/Marcas registradas utilizadas en algunos paises del mundo bapo licencia de/Marcas registradas utilizadas en algunos paises del mundo bapo licencia de/Marcas registradas en de/Marcas registra ment extraction (CA) 90801 • Distributed in the European Union by Distributed and Union European Union by Distributed dans Union European en experiment e

## SAVE THESE INSTRUCTIONS

Page 2